

GSI Lumonics

M2 / M2T 9.5 mm Reference Manual

**Open Frame Head
with
6U EDD Style Drivers**

**60 FORDHAM ROAD
WILMINGTON, MA 01887**

**GMAX™ SYSTEMS
MULTI-AXIS BEAM HANDLING**

TABLE OF CONTENTS

1. INTRODUCTION	1
1.1 Warranty.....	2
1.2 Customer Support	3
1.3 Unpacking	3
2. GENERAL DESCRIPTION	5
2.1 Scan Head Types.....	5
2.2 Mirror Types	6
2.3 Controller Types	6
3. SAFETY AND WARNINGS	7
3.1 Laser Shutter Installation	9
3.2 Installation Safety Requirements	10
4. OPERATION.....	11
4.1 Installation	11
4.2 Operating Instructions	11
4.2.1 Driver Card Description	12
4.2.1.1 Features	12
4.2.1.2 Power Requirements	12
4.2.1.3 The SIC Backplane Card.....	12
4.2.1.4 Scanner Cable.....	12
4.2.1.5 Front Panel Indicators	12
4.2.1.6 Address Selection.....	12
4.2.1.7 Diagnostic Connector	13
4.2.1.8 Setting for External or DAC Input	13
4.2.1.9 Traditional Temperature Controller	13
4.2.2 Scan Head Description	13
4.2.2.1 Scanner.....	14
4.2.2.2 Mirrors	14
4.2.2.3 Scan Angle.....	14
4.2.2.4 Outline and Mounting	14
4.2.2.5 Thermal Behavior -- Maximum Allowable Temperature	14
4.2.2.6 Current Cutoff Circuit.....	15
4.2.2.7 Dynamic Heating by Coils.....	16
4.2.3 System Performance Data (Dynamics)	16
5. OPERATING ENVIRONMENT	17

6. HANDLING / MAINTENANCE 19

 6.1 Mirror Cleaning..... 19

7. APPENDIX A 21

 7.1 Mirror Selection Guide..... 21

 7.1.1 Aperture Considerations 21

 7.1.2 Types of Mirrors..... 22

 7.1.3 Use in XY Scan Heads 23

 7.1.4 Accuracy..... 23

 7.1.5 Mirror Flatness Standards..... 24

 7.1.6 Scratch and Dig Specifications 24

 7.1.7 Reflectivity 25

 7.1.8 Special Example -- Computing Power Capability of CO₂ and YAG Mirrors 26

 7.2 Image Distortions 27

 7.2.1 OPD Distortion..... 27

 7.2.2 Cosine (COS) Distortion 28

 7.2.2.1 COS Image Distortion 29

 7.2.2.2 COS Focus Distortion..... 30

 7.3 Drive Signals 31

 7.3.1 Step 31

 7.3.2 Vector 32

 7.3.3 Raster 33

 7.4 XY Calculations..... 35

 7.5 Linearity Distortions..... 37

8. APPENDIX B 41

 8.1 Outline Drawings / Data Sheets 41

1. INTRODUCTION

GSI Lumonics 2-mirror, 2-axis XY galvanometer based Scan Heads provide the capability of deflecting optical beams in laser and vision applications. In laser writing, the XY Scan Head requires a light source focused through the XY Scan Head onto a target. The XY Scan Head then directs the focused spot to generate raster or vector patterns as programmed. For vision, these Scan Heads are used with CCD and Vidicon cameras, or with single-point detectors such as photomultipliers. Like the human eye, the XY Scan Head directs the image path to view different target areas. Typically, the Scan Head executes RANDOM ACCESS motions to acquire various images for vision system evaluation.

This manual describes GSI Lumonics M2 and M2T 9.5mm XY Open Frame Head with EDD drivers. It is ideally designed for vector applications. Raster applications are also well suited with this product when temperature monitoring and control is incorporated in the system design.



WARNING

As a component in a system, instructions for the safe installation and usage of systems that use GSI Lumonics XY Scan Heads should be obtained from the manufacturer of the complete product.

Conventions

Throughout the manual you will see graphic icons representing pertinent information in the text. The purpose of these icons is to provide a visual convention to alert you of a stop in the flow of the manual, where an important note or safety hazard alert is posted.






NOTE is an important procedure you should be aware of before proceeding.

CAUTION alerts you of a potential danger to equipment or the user.

WARNING indicates an imminent danger to the user.

TIP and **REMINDER** are helpful hints to procedures listed in the text.

The conventions are listed as follows, showing both the text and the picture you will see.

NOTE	CAUTION	TIP	WARNING	REMINDER
				

1.1 Warranty

GSI Lumonics warrants this product to be free from defects in materials and workmanship for 12 months from the date of shipment. GSLI will, at its option, repair or replace the product if it is defective within the warranty period and returned, freight pre-paid, to a service center designated by GSLI.

GSI Lumonics requests that customers obtain a Return Authorization Number prior to returning units, and that they carefully pack units in their original packing or equivalent.

Under warranty, GSLI is not obligated to repair damage to any units resulting from the following conditions (customers are responsible for defining which conditions are applicable to their product):

- a) Personnel other than GSLI representatives attempting to repair or service the product.
- b) Improper use of the equipment.
- c) Connecting the product to incompatible equipment.
- d) Personnel other than GSLI representatives modifying the product.
- e) Scratches and chips on any optical surface after three weeks from the date of receipt.
- f) Damage to any optical surface from improper handling or cleaning procedures. This applies specifically to those items subjected to excess laser radiation, contaminated environments, extreme temperature or abrasive cleaning.

Customers assume all responsibility for maintaining a laser-safe working environment. OEM customers must assume all responsibility for **CDRH** (Center for Devices and Radiological Health) certification.



NOTE

There is no implied warranty of fitness for a particular purpose, and GSLI is not responsible for consequential damages. Individual components manufactured by GSLI or others may be covered by their own warranties. Refer to the appropriate manuals for this information.

1.2 Customer Support

GSI Lumonics has support services available to you concerning problems with either the product or manual you are using.

Before calling for assistance, please make sure you refer to any appropriate sections in the manual that may answer your questions. The “Outline Drawings / Data Sheets” in Appendix B may be particularly helpful. If you need further assistance:

The customer service personnel will be able to give you direct assistance and answers to your questions.



U.S. (Massachusetts):	(978)-661-4300 (in the U. S.) +01-978-661-4300 (outside the U. S)
Germany (Munich):	+49 89 899134-0
Italy (Monza):	+39 39 2025387
UK (Banbury):	+44 132-787-2424
Japan (Tokyo):	+81 3 3406 7990

... ask for the GMAX Customer Service Department

1.3 Unpacking

The package you receive will include those items mentioned in the packing list is included in the shipment that details the exact items shipped.

- a) CAREFULLY unpack the contents from the box.
- b) Save shipping container and packaging material in case you need to return unit for service.
- c) Check contents of the box against the packing list to assure all parts have been received.
- d) Inspect each item to assure it is not damaged.

2. GENERAL DESCRIPTION

Enclosed with this package are the following:

ITEM	QTY
6U EDD Style Driver card	2 (tuned for XY)
XY Head w/ XY mirrors	1

Each Scan Head is unique in the servo parameters it requires for optimum operation. Therefore, each XY Scan Head must be used with its calibrated driver. See Section “Operation” on page 11 for information regarding system set up.

2.1 Scan Head Types

Scan Head Types with Part Numbers

SCANNER	APERTURE	MIRROR	PART #S
M2 w/EDDs; no enclosure (OEM)	9.5 mm	UV	E00-7010530
“	“	Ag	E00-7010543
“	“	Ar	E00-7010019
“	“	Ar (high power)	E00-7010020
“	“	YAG	E00-7010017
“	“	CO ₂	E00-7010018
M2Tw/EDDs; w/Baseplate (OEM)	9.5 mm	UV	000-3010527
M2Tw/EDDs; (OEM)	“	UV	000-3010528

2.2 Mirror Types

	LASER TYPE					
	YAG	CO2	ARGON	ARGON (HP)	UV	VISIBLE
Aperture (mm)	9.5	9.5	9.5	9.5	9.5	9.5
Wavelength	1,064 nm	10,600 nm	488-514 nm	488-514 nm	325-360 nm	450-700 nm
Coating	Dielectric	Dielectric on Metal	Dielectric	Dielectric	Dielectric	Durable Ag
Reflection (min.) @ Wavelength (nm)	99.5% @ 1,064 80.0% @ 450-650	99.5%	98.0% @ 480-514 50.0% @ 633	99.5%	98.0% @ 325-350 95.0% @ 350-360 45.0% @ 633	96.0%
Flatness @ 633 nm	$\lambda/4$	$\lambda/4$	$\lambda/4$	$\lambda/4$	$\lambda/4$	$\lambda/4$
Power Capability, cw (W/cm ²)	500	500	100	5 MW/cm ²	50	10
Power Capability, 100 ns pulsed (MW/cm ²)	100	400	80	2 GW/cm ² (10 ns pulsed)		
Surface Quality (Scratch/Dig)	40/20	40/20	60/40	40/20	40/20	40/20

See your GSI Lumonics sales representative for more details.

2.3 Controller Types

The EDD cards are designed for use in a number of different DSC scan controller configurations. These include use with advanced GMAX software through interface connections to GSI Lumonics PC based HelperCard series (DSC with HCI card) and the traditional Digital Scanning Controller (DSC with DIC card). The DSC3000 nomenclature references a full 19" width 6U high rack.

Controller Types with Part Numbers

CONTROLLER	PART #S
DSC2000/M (HCI; no EDDs)	E00-7017512
DSC2000/M (DIC; no EDDs)	E00-7017014
DSC3000/M (HCI; no EDDs)	E10-178191
DSC3000/M (HCI & LT EDD only)	E00-7017525
DSC3000/M (HCI & LT EDD only; PostGrid Softw.)	E10-155141
DSC3000/M (DIC & LT EDD only)	E00-7017507
DSC3000/M (DIC; no EDDs)	E00-7017517

3. SAFETY AND WARNINGS

The United States Food and Drug Administration, through the Center for Devices and Radiological Health (CDRH), has promulgated regulations (21 CFR parts 1000 and 1040) controlling the safety of lasers and laser products for sale or manufacture in the United States. GSI Lumonics **XY Scan Heads** are regulated by the CDRH.

This section is a guide to the specific areas of this product and to the manual(s). Pay particular attention to CDRH compliance information.

*User
Responsibilities*

GSI Lumonics **XY Scan Head** are designed to provide maximum flexibility and ease of use. Such a design inherently requires the user to assure the overall safety of the configuration in use.

It is the user's responsibility to insure that:

- 1) Only lasers certified to comply to CDRH regulations are used with GSI Lumonics **XY Scan Heads**.
- 2) Certified lasers contain features to assist in their safe usage. These protective features and the protective features within the GSI Lumonics **XY Scan Heads** should not be defeated.



CAUTION

Prior to operating any configuration of the GSI Lumonics XY Scan Heads, you must make a through analysis of system safety. Key information for this purpose is contained in this manual. You would thoroughly familiarize yourself with all this information before proceeding.

Laser Hazard Analysis

A full description of laser hazard analysis is beyond the scope of this manual. A good technical survey of laser safety requirements can be found in **ANSI Z136.1, "American National Standard For the Safe Use of Lasers"**. This is available from:

*American National Standards Institute, Inc.
1430 Broadway
New York, New York 10018*

Among the many other sources of laser safety information, the following institution offers several excellent publications.:

*The Laser Institute of America
5151 Monroe Street, Suite 118W
Toledo, Ohio 43623*

Final analysis of all safety features should be made by your Laser Safety Officer or a competent specialist in this field.

The first consideration in a safety analysis is the laser mated to the GSI Lumonics **XY Scan Head**. The hazard level of the laser is roughly indicated by the Laser Class label that is on the device. A brief description of the radiation classes are shown in the following table.

Note that, besides radiation, lasers may present other hazards, e.g.; electric shock or creation of poisonous fumes.

Classes and Characteristics of Lasers

LASER CLASS	DESCRIPTION
Class I	Lasers are not considered to be hazardous.
Class IIa	Lasers are hazardous if viewed for periods greater than one thousand seconds.
Class II	Lasers are chronic viewing hazards.
Class IIIa	Lasers may represent acute, intrabeam viewing or chronic or acute viewing hazards when viewed with optical instruments.
Class IIIb	Lasers are an acute hazard to skin and eyes from direct radiation.
Class IV	Lasers are an acute hazard to skin and eyes from direct or scattered radiation.




CAUTION

Do not use equipment outside of these ranges, as additional hazards may result.

Because we do not determine the laser used with our product, all GSI Lumonics end-user **XY Scan Heads** are labeled at the highest hazard level (Class IV). You should obtain information on output power or energy, wavelength(s) of output, duration of pulse, beam size and beam divergence from the manufacturer of the laser you are using.

The wavelength and power of the laser actually used should be written on the warning logo type label, Position 2. (See Section page 33699 and 33700 of the Federal Register, Appendix B). Be sure to use a permanent, indelible ink.

Class IV Warning Label



The Federal Register Rules and Regulations, Vol. 50, No. 161, dated Tuesday, August 20, 1985, contains the performance standards adopted by the Food and Drug Administration (FDA) which gives detailed information regarding the determination of laser classification and labeling. The ANSI and the FDA classifications are not the same. For purposes of labeling, use only the FDA classifications. If your laser falls in a classification below Class 4, replace the warning label type with the correct label and appropriate classification. The factory provides alternate labels upon request.



REMINDER


The GSI Lumonics **XY Scan Heads** provide you with the ability to aim the laser beam over a roughly pyramidal volume. The divergence of the focused beam beyond the focal point, which is a function of the lenses selected and their position, can cause radiation to exit the pyramid. When analyzing safety, you must consider all regions within this aiming pyramid, the divergent beam, and the effects of all focal possibilities in the zone of hazard. Reflections must also be considered.

3.1 Laser Shutter Installation




The laser attenuator (shutter) is not included with the **XY Scan Head**. Because each laser is unique, it is the user's responsibility to insure that such a device is incorporated in the installation in conformance with CFR regulations (1040.10[f][6]), which reads as follows:
 A beam attenuator is required on Class II, IIIa, IIIb and IV laser systems. The beam attenuator is a mechanical or electrical device such as a shutter or attenuator that blocks emission. The beam attenuator blocks bodily access to laser radiation above Class I limits without the need to turn off the laser. The beam attenuator must be available for use at all times during operation. Power switches and key controls do not satisfy the attenuator requirement.

Example of Laser Shutter Location in a HPM System




The beam shutter should be installed between the laser head and the Scan Head. The following figure shows the recommended location of the shutter.



We strongly recommend that you specify a laser with a vendor-supplied shutter mechanism. If this is not possible, consult the laser vendor to design a proper safety shutter.

Laser Scanner Hazard Zones of an HPM Scan Head



The figure shows the laser's internal and external optical path towards the target plane, specifically where the hazard zones are located as the optical beam passes through as **HPM Scan Head**

3.2 Installation Safety Requirements

Because of the possible hazard increase of scanning stopping or slowing to an unsafe velocity, it is required that the controller software shuts down the laser power (a scanning safeguard).

In all cases, we recommend that you fully enclose and interlock the zone of hazard for your application to prevent possible opening while the laser is energized. When laser radiation exceeding Class 1 levels may exit the enclosure, you must have suitable protection for eyes available.



NOTE

At no time should you stare into the beam, place any parts of your body in the beam path, or expose yourself to reflections of powerful beams. You should use only a Class 1 HeNe Laser for alignment. If this is not possible, you should use the available laser's lowest power setting and remote beam sensing technique.



CAUTION

Using optical instruments with this product increases eye hazard.

Additional Safety requirements may be applicable during initial alignment of the optical system. Refer to Section, “Safety and Warnings”, Section 3.

GSI Lumonics XY Scan Heads are labeled in conformance to the requirements of 21 CFR parts 1000 and 1040.

4. OPERATION



CAUTION

Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure!

4.1 Installation

Installation of the XY Scan Head is relatively simple. Four holes that will accept 1/4" screws have been provided in the baseplate. Additionally, two dowel pins have been placed in the baseplate, allowing repeatable alignment of the XY Scan Head to it's mounting surface. Refer to outline drawings in the appendix for exact locations of these features.

After securely mounting the XY Scan Head, connect the drive cables provided to the X and Y servos. If you have purchased GSI Lumonics controllers, the X and Y servo drivers are clearly identified on the front panel. Be careful to connect the X servo on the XY Head to the driver card labeled X servo and the Y servo on the XY Head to the driver card labeled Y servo. Tighten screws to capture the connectors.

4.2 Operating Instructions

GSI Lumonics XY Scan Heads have been designed to provide optimal performance when driven with a number of different scan controllers. The EDD cards are designed for use in a number of different scan controllers. These include use with advanced GMAX software through interface connections to GSI Lumonics PC based HelperCard series (DSC with HCI card) and the traditional Digital Scanning Controller (DSC with DIC card). The DSC3000 nomenclature references a full 19" width 6U high rack.

*DSC Types with
Part Numbers*

CONTROLLER	PART #S
DSC2000/M (HCI; no EDDs)	E00-7017512
DSC2000/M (DIC; no EDDs)	E00-7017014
DSC3000/M (DIC & LT EDD only)	E00-7017507
DSC3000/M (DIC; no EDDs)	E00-7017517

The controller user manual provides all necessary information for the safe operation of the XY Scan Head.

4.2.1 Driver Card Description

4.2.1.1 Features

The driver card is configured specifically for use with M class scanners with sum-dif ($\Sigma\Delta$) detector configurations. In many ways it is identical to the M3H driver.

*Pertinent Features
Include*

Feature	M3	$\Sigma\Delta$
output stage	double push pull	double push pull
detector input	voltage mode	sum dif derived AGC
servo feedback controls	vel, err, int, pos	vel, err, int, pos
input filters	none	slew rate limiter
scanner protection	fuse	fuse and temperature estimation
mechanical	6U Euro (DIN) std	6U Euro (DIN) std
backplane	M3H type	M3H type

4.2.1.2 Power Requirements

The analog section and scanner power amp requires $\pm 18V @ 1A$ continuous and 5A peak. The digital portion requires $5V @ 1A$ max.

4.2.1.3 The SIC Backplane Card

Each driver must interface through the “Scanner Interface”. This is identified by the dual connectors for the galvo cable. It is the same used for the M3H.

4.2.1.4 Scanner Cable

To connect the scanner to the SIC backplane use the same cable used with the M3H. Note that the M2 called for has a 15 pin connector.

4.2.1.5 Front Panel Indicators

Three green indicators signal status of the scanner-driver:

- **In Field**
when lit indicates the galvo is operating within its rated angle.
- **Tracking**
when lit indicates the difference between command and position (error) is lower than a preset limit. Blinking may be normal in applications with high slew rate commands.
- **Power**
when lit confirms that ± 18 and $+5 V$ supplies are operating.

4.2.1.6 Address Selection

W5 is configured to set the strobe select address and status signal read back. W5 is found on the PCB in the exposed section towards the DIN connectors. Configure the jumpers connecting as the shaded segments show in the following chart(s).

GMAX M2/M2T 9.5mm XY Open Frame Head

*W5 Jumper Settings,
"X"*

2	4	6	8	10	12	14	16	18
1	3	5	7	9	11	13	15	17

*W5 Jumper Settings,
"Y"*

2	4	6	8	10	12	14	16	18
1	3	5	7	9	11	13	15	17

*Resulting Outputs on
I/O Bus*

ADDRESS LINES A4 A3 A2 A1				SELECT MODULE
1	X	0	1	Y servo
1	X	1	1	X servo

4.2.1.7 Diagnostic Connector

The following signals are available on the diagnostic connector.(located on SIC backplane)


*Diagnostic
Connector*

SIGNAL	PIN	PIN	SIGNAL
AGC Volts	1*	2	scanner I @ 1V/Amp
DAC out w/slew rate	3	4	signal ground
position out	5	6	external POS in $\pm 5V$
10X POS Err out	7	8	velocity out
NC	9	10	NC

*key

4.2.1.8 Setting for External or DAC Input

The board can be configured for either DAC or Analog input through the diagnostic connector.




NOTE

Only the DAC analog passes through the slew rate limit circuit. Analog inputs will not be slew rate limited.

To make the selection remove the front panel via six Phillips head screws. Locate segments 5 and 6 labeled DAC ENBL and EXT ENBL. Left-left (close-close) enables DAC input and disables external input. Right-Right enables external input.

4.2.1.9 Traditional Temperature Controller



NOTE

This driver includes a traditional temperature controller which is wired to the backplane. The M2 does not use this capability.

4.2.2 Scan Head Description

4.2.2.1 Scanner

M2 with 15 pin connector. See the data sheet in Section “Outline Drawings / Data Sheets”, Appendix B.

4.2.2.2 Mirrors

9.5 mm clear aperture. See options in Section “Mirror Types” on page 5.

4.2.2.3 Scan Angle

± 21 optical (clear aperture), calibrated for ± 20 ($\pm 0.5\%$).

4.2.2.4 Outline and Mounting

See Section “Outline Drawings / Data Sheets”, Appendix B, for an outline drawing.

4.2.2.5 Thermal Behavior -- Maximum Allowable Temperature



NOTE

The following “Thermal Behavior” discussion is most important for raster applications. Vector applications typically require only 0.1 W to 1.0 W (0.2 °C rise) of applied power to the scanner.



WARNING

Failure to perform these measurements and calculations for raster applications may result in significant scanner damage caused by an over-temperature condition. The current cutoff circuitry in the driver electronics (described in Section “Current Cutoff Circuit” on page 15) will only protect the scanner if the scanner mount temperature is held below 48 °C.

The scanner temperature is limited by a maximum allowable coil temperature of 100 °C. It is critical that the coil temperature does not exceed 100 °C for each application of this Scan Head. This coil temperature may be estimated by the method below.

1. Determine the pattern which has the highest RMS power. This power may be measured by connecting a true RMS meter to the “drive current” output of the diagnostic connector. This RMS current is then multiplied by the coil resistance at 100 °C (6.05 ohms) to determine power. Do not apply this pattern for more than 5 seconds until the power has been calculated or damage may result.
2. Next, measure the maximum scanner case temperature under conditions of maximum internal system ambient temperature and zero internal scanner power.
3. The preliminary coil temperature is calculated by adding the scanner temperature rise (power times 2.5 °C/W scanner thermal resistance) to the maximum scanner case temperature.
4. If the coil temperature calculated in (3.) above is acceptable, apply maximum scanner drive power and again measure the scanner case temperature. Recalculate the coil temperature.

4.2.2.6 Current Cutoff Circuit



WARNING

The circuit described below is sensitive to RMS current only and not coil temperature. It is essential that the user perform the above calculations to prevent malfunction or damage to the scanner.

Should the current cutoff circuit cause the scanner to operate intermittently the user should cease operation immediately and review his input drive command.

There is a current cutoff circuit on each driver board which calculates RMS current in the scanner coil and disconnects the driver when the current exceeds 1.7 amps RMS (square wave input) and 1.42 amps RMS (sine wave) steady state for 30 seconds. The power permitted at these currents must be calculated using the coil resistance at the galvo operating temperature. The power at room temperature (25 °C) is calculated using a coil resistance of 4.65 ohms. At 100 °C, the power is calculated using a coil resistance of 6.05 ohms. Since the circuit has a built in delay, the current may exceed these values for periods of time shorter than 30 seconds. For instance, the circuit will permit 2.13 amps (square wave) for 13 seconds. This circuit should prevent coil damage under most long-term over power situations, but does not eliminate the possibility of damage due to brief fault conditions involving significantly higher currents. **In summary, this circuit will not prevent damage due to unusual fault conditions during tuning or system debug.**

4.2.2.7 Dynamic Heating by Coils

This is the standard open frame Scan Head with high conductance mounting rings installed between the scanners and bracket. These have a thermal impedance of approximately 0.6 °C /W. This, combined with the M2 coil impedance of 2.5 °C/W, can be used to calculate a max. average power capacity; for example:


$$(100\text{ }^{\circ}\text{C}_{\text{coil max}} - 30\text{ }^{\circ}\text{C}_{\text{frame ambient}}) / 2.5\text{ }^{\circ}\text{C/W} = 25\text{W}$$



NOTE

Because the internal temperature of the scanner varies with coil heating some thermal drift will occur. A coefficient of approximately 100 PPM gain per °C of coil temperature can be anticipated.

Heat Sinking Test



In the Scan Head supplied, heat sinking tests resulted in the following typical values:

R_c	=	2.5 °C/W
R_m	=	0.6 °C/W
R_{total}	=	3.1 °C/W

4.2.3 System Performance Data (Dynamics)

System

Slew rate limiter setting	375 rad/sec
Tracking offset	340E-6 rad*sec/rad _{2,3})
Spec. Velocity	10 rad/sec
Spec. Velocity Settling	1.5 msec
Tracking Linearity	300E-6 Rad ₃)
Step and settle (7 mrad)	1.5 msec (to 70E-6 Rad err)

Notes:

- 1) All angles in optical radians.
- 2) rad*sec/rad * rad/sec (vel) = position lag in radians.
- 3) May be converted to volts by 10V/.698 rad.

5. OPERATING ENVIRONMENT

The following recommendations cover the handling, use or storage of Scan Heads.

*Environmental
Requirements*

Storage Temperature:	-10°C to +60°C
Minimum Operation Temperature:	+15°C
Maximum Operating Temperature:	+34°C
Humidity:	Non-condensing

6. HANDLING / MAINTENANCE

The GSI Lumonics XY Scan Head does not contain any user serviceable or user maintainable parts. However, you should visually inspect all optical surfaces each time lenses and alignment mirrors are handled.



NOTE

Make sure that the laser is off before performing any inspections! Wear finger cots or cotton gloves when handling optics for inspection.

All contamination on optical surfaces must be removed prior to operation or serious damage and/or hazard may result. The Scan Head must be protected from airborne contaminants. Dust attaching through impact or heating and vapors condensing on the optical surfaces reduces the mirror's reflectivity. Furthermore, avoid scanner exposure to dust, condensation or cleaning fluids in the exposed bearing area.



CAUTION

You must be extremely careful not to allow contamination from entering the galvanometer through its exposed bearing. Serious scanner damage may result.

If you feel that cleaning or service is necessary, contact the customer service group at General Scanning for information regarding service.

6.1 Mirror Cleaning

Although the mirrors can be replaced by the user, we do **not recommend** you do so. Furthermore, **GSI Lumonics does not recommend cleaning front surface mirrors.** Mirrors damaged by cleaning are not included under the warranty. The surface of these mirrors damages easily. It is difficult to prevent hard dust particles from being entrained in the process and causing scratches. In many cases, small defects in the mirror's surface may be less harmful than the surface damage resulting from continued cleaning. It requires special equipment typically not available to customers.

There are times, however, when cleaning the mirror becomes a necessity, e.g. stains such as fingerprints must be removed immediately to prevent permanent etching of the reflective surface. The information below includes general recommendations for those special occasions when mirrors must be cleaned.

Removing Dust

Remove lint from mirrors with a jet of low pressure clean air. Blowing on front surface mirrors deposits moisture that may stain the finish.

Removing Stains

A thin overcoating of silicon monoxide protects most mirrors from oxidation. Like many optical coatings, it is easily damaged when attempts are made to clean the mirror surface with a dry tissue.

The safest method of cleaning is to place a piece of lens tissue on the mirror surface and wet it with reagent grade (highly pure) alcohol or acetone (If you use acetone, take precautions regarding possible health and fire hazards). Grasp an overhanging corner of the tissue and gently agitate it several times, then slide the tissue off. This should remove the problem blemishes.



CAUTION

Do not let solvent enter the bounding zone of the mirror.



NOTE

Note that the mirror is not rubbed.

If the mirror surface is still contaminated, use a highly pure solvent such as alcohol or acetone and generously wet the mirror surface with a **sterile** cotton swab or lens tissue. Gently wipe the dirty areas. Turn your cotton swab or tissue with each stroke so that a clean area is exposed.



CAUTION

Do not let solvent enter the scanner bearings. When wetting the mirror's surface, hold the scanner at an angle so that the liquid does not wet the scanner. If any solvent is found in the bearings of the scanner, the warranty is voided.

7. APPENDIX A

7.1 Mirror Selection Guide

7.1.1 Aperture Considerations


Aperture

The **aperture** of the Scan Head is the limiting opening through which the optical system must image. The most important trade-off to recognize when selecting a Scan Head is that larger apertures provide better optical properties but slower motion capability. A two-mirror, two-axis Scan Head has a number of distinct apertures. One or more of the apertures determine the pupil of the Scan Head in any given situation.

These apertures are:

- EA:** Entrance Aperture, or location where the Scan Head structure limits the size of a lens element. This is the usual location of the last imaging element. The EA defines the maximum allowable diameter of a lens and its housing.
- X_n:** X mirror near aperture is sized and located by the near edge of the X mirror when rotated to its shallowest angle, typically 35 degrees mechanical.
- X_f:** X mirror far aperture is similar to X_n, but it is sized and located at the far edge of the X mirror. Generally X_f does not come into play in computations.
- Y_n:** Y mirror near is the Y mirror counterpart of X_n.
- Y_f:** Y mirror far is the Y mirror counterpart of X_f. Unlike X_f, it will be important in certain vision computations.
- X_c:** X mirror clip is the beam radius to the corner of the X mirror, viewed by the Y mirror. This occurs when the scanners are pointed to the extreme lower right-hand corner of the field.
- S:** Distance from EA to the surface of the X mirror nearest the axis of rotation, in the center of rotation. S_{xn} and S_{yn} are similarly located.
- E:** Distance from (a) to the surface of the Y mirror nearest the axis of rotation, in the center of rotation (b).

Positions of Apertures



Typical Aperture Dimensions of Some XY Scan Heads (mm)

XY Head	EA	S	S _{xn}	X _n	E	S _{yn}	Y _n	S _{xc}	Y _f	X _c	Lim Apert.
5 mm	66.0	40.0	3.6	5.0	7.0	2.3	5.0	n/a	5.0	≥ 2.5	X _n

10 mm	30.0	28.4	7.1	10.0	13.0	5.5	10.0	n/a	10.0	≥ 5	X _n
20 mm	38.1	25.2	14.3	20.0	26.0	11.3	20.0	n/1	20.0	≥ 10	X _n
30 mm	50.8	28.4	21.4	30.0	37.0	14.4	27.7	20.3	26.1	11.7	Y _n
50 mm	58.0	70.0	35.7	50.0	67.0	22.1	47.4	42.4	46.4	22.6	Y _n

7.1.2 Types of Mirrors

To optimize their performance, GSLI Scan Heads incorporate one or more of the mirror constructions described below.


First Surface Mirrors

First Surface Mirrors are designed with the reflective surface on the axis of rotation. This simplifies the computation of dynamic geometric correction (discussed in Section “XY Calculations” on page 35) Unfortunately, it also creates a lateral imbalance in the scanner when the mirror rotates. First surface mirrors are restricted to scanners carrying apertures either outboard supported, as in the 50 mm Scan Head, or structurally stiff enough, as in the 10 mm and 20 mm Scan Heads.

Mass Balanced Mirrors

Mass balanced mirrors position the mirror mass in a balanced configuration about the scanner's axis of rotation, thus eliminating lateral forced due to rotation. This allows less robust scanner structures to more easily support large aperture mirrors. This increases the sensitivity of the input beam to mechanical alignment errors and adds a small amount of X, Y and focus linearity error. For scan radii greater than a few hundred times the mirror offset, these errors become negligible.

Type of Mirrors



Typical Surface Offset Dimensions for XY Heads

MIRROR SIZE	OFFSET
5 mm	0.5 mm
10 mm	1.5 mm
20 mm	1.5 mm
30 mm	2.0 mm

Inertially Matched Mirrors

Inertially Matched Mirrors are designed with X and Y mirrors having nearly the same moment of inertia. This allows the scanners to be tuned to match each other and improves vector performance. The small reduction in Y aperture matches typical laser focus cones. A canting of the X axis also increases the Y incident angle. These serve to reduce Y inertia to match X.

7.1.3 Use in XY Scan Heads

The three basic configurations of Scan Heads are:

- **STD 45 Degrees Heads**

These are the simplest to configure. Each mirror is designed to reflect the beam at a nominal incident angle of 45 degrees, therefore the Y axis is directly over the X axis.

- **Y Optimized Heads**

These rotate the X axis 5 to 15 degrees, reducing the required width of the Y mirror by a more normal angle of incidence. In some cases this allows the inertia of the Y mirror to be reduced to match the X. The disadvantage is the possibility of "X mirror clip" occurring. This may happen when the Scan Head is directed to the lower right corner of the field. The corner of the X mirror may clip the Y output beam. Where applicable this is specified in the aperture specifications as a clipping beam radius.

- **Outboard supported Scan Heads (XY5067 only)**

This Scan Head uses a specially designed outboard bearing and drive coupling to support the mirrors. It is implemented in cases where the bending inertia of mirror loads exceeds practical scanner limits.

7.1.4 Accuracy

As a general rule the accuracy constraints of the Scan Heads in this manual are the following:

- **Accuracy**

The accuracy (derived from non-linearity in scanners) of the angular position at rest +/- 0.3% of full field. For a +/-20 degrees scan, the maximum error would be +/-7 min. arc, or +/-2 milli-radians in each axis.

- **Mirror Angles**

The mirror angles to the mounting references are within +/-10 milli-radians and within +/-6 milli-radians to each other.

- **Mirror Axes**

The mirror axes are true position to the mounting references within +/-0.015 inches (+/-0.38mm).



NOTE

This is not a guaranteed specification for all configurations. If more stringent tolerances are needed, consult the factory for recommendations.

7.1.5 Mirror Flatness Standards

For the optical system to perform the mirror surface must be of adequate flatness to prevent degradation of the image.

The next table lists recommended minimum specifications for various pupils and applications.

Typical Mirror Flatness for XY Heads

APERTURE	POWER (FRINGES)	IRREG. (FRINGES)
5 mm	1/2	1/2
10 mm	1/2	1/2
20 mm	1/2	1/2
30 mm	1	1
50 mm	1 1/2	1 1/2

Notes:

1. Fringes are equal to 1/2 wave OPD (Optical Path Distortions) at 633 nm. For longer wavelengths the effect of OPD must be scaled inversely to the wavelength (refer Section "Image Distortions", Section 7.2).
2. Power refers to the symmetrical, spherical distortion of the surface in fringes. Power degrades optical performance to a lesser degree than Irreg.
3. Irreg. refers to the non-symmetrical commonly cylindrical distortions of mirror surfaces. It is the key offender in the OPD deformities of out of round spots and astigmatism.

Recognizing Flatness Problems

Mirror non-flatness in imaging systems usually appears as astigmatism in the image. That is, vertical and horizontal axes do not focus optimally at the same plane. In focused laser spots, the spot is oval, and in vision images, the vertical and horizontal image features do not focus at the same planes.

7.1.6 Scratch and Dig Specifications

Scratch/Dig

A mirror is surface specified by a **scratch/dig** notation such as 40/20, 40 referring to the scratch and 20 to the dig number.

Scratch

A **scratch** is a gouge or tear in the mirrors reflective surface. The scratch number defines the sum of the scratch widths in micro-meters. That number must not be exceeded when all the scratches in the useful aperture are summed.

The sum of the lengths of all the scratches in the useful aperture must not exceed 1/4 of the useful aperture diameter.

Digs

Digs are pits or gouges, more or less round in nature. When summed, all the "dig" diameters in the useful aperture must not exceed the dig number times 10 micro-meters.



NOTE

In the Y Mirror of many Scan Heads, the useful aperture is defined by a moveable ellipse of the size typical of the image beam on the mirror, not the full mirror for both scratch/dig and flatness.

Common Scratch/Dig Call-outs

SCRATCH/DIG	DESCRIPTION
-------------	-------------

GMAX M2/M2T 9.5mm XY Open Frame Head

10/5	Highest quality laser surface. Scatter free.
20/10	Laser quality. Used particularly with smaller apertures where scatter or interference patterns cannot be tolerated.
40/20	Very good optical quality. Beam splitters and laser photographic. The small defects have little effect on relatively large apertures.
60/40	General optical quality. Visual optics and general purpose laser photographic.
80/50	Good plate glass quality.


*Typical XY Head
Mirror Scratch/Dig
Specifications*

APERTURE	SCRATCH	DIG
5 mm	20	10
10 mm	40	20
20 mm	60	40
30 mm	60	40
50 mm	80	60

7.1.7 Reflectivity

Reflectivity is measured by the ratio of incident to reflected light at $45 \pm 10^\circ$.


*Example:
First Surface Mirrors
Normal to 45°
Incidence*



Legend:

- A: Protected aluminum
- B: Enhanced aluminum (non stock, ref. only)
- C: Durable silver
- D: First surface gold (non stock, ref. only)

Example: Theoretical Reflectivities of Dielectric on Silver Coatings



Legend:

- A: Polarization, 10.6 μm
- B: Polarization, 10.6 μm
- C: Polarization, 1.06 μm
- D: Polarization, 1.06 μm

7.1.8 Special Example -- Computing Power Capability of CO₂ and YAG Mirrors

The power capability of high power laser working mirrors can be computed. Assume the reflected beam is a TEM₀₀ Gaussian beam. The table below gives peak irradiance capability. Compute the total power for a 2/3 filled aperture in Watts, given the peak irradiance (Ip), aperture (Ap), as follows:

$$\text{Watts} = \frac{I_p \cdot \text{PI} \cdot A_p^2}{18}$$

This equation assumes that the 1/e² diameter is 2/3 filling the aperture, which ensures that 99% of the power is transmitted.

Should there be extra power, 86% transmission is acceptable. The full 1/e² diameter may fill the mirror providing a beam stop aperture is supplied prior to the Scan Head. This ensures fringe energy does not overheat the mirror mounts and the surrounding scanners. Compute the total beam power for a filled aperture as follows:

$$\text{Watts} = \frac{I_p \cdot \text{PI} \cdot A_p^2}{8}$$



CAUTION

Any contamination on a high power mirror surface degrades its capability. Contamination must be considered when figuring power capability.

GMAX M2/M2T 9.5mm XY Open Frame Head

Safe Peak Irradiance Capability

WAVELENGTH	CE PEAK IRRADIANCE	PEAK PULSED IRRADIANCE
10.6 μm	500 W/cm ²	400 MW/cm ²
1.06 μm	100 W/cm ²	80 MW/cm ²

Laser Power Capability for Mirrors (2/3 Filled Aperture)

APERTURE	1.06 μm PULSE	1.06 μm CW	10.6 μm PULSE	10.6 μm CW
10 mm	14 MW	18 W	72 MW	87 W
20 mm	56 MW	70 W	280 MW	350 W
30 mm	125 MW	156 W	624 MW	780 W

Among the Variations to Consider

For the same reasons as CW lasers, pulsed laser power must be examined for peak irradiance of the pulse for damage threshold and also for average power. If the beam is multi-mode, estimate its peak irradiance from profiles supplied by manufacturers.

7.2 Image Distortions

Two types of image distortions are of principal interest:

1. OPD (Optical Path Distortion) causes imaging distortions. These are dependent on mirror quality only. Scan angle does not affect the results.
2. Cosine distortion causes spot elongation for laser and compression of the image frame for vision. Both occur approaching the field edges.

7.2.1 OPD Distortion

Optical Path Distortion may be caused by the Scan Head or imaging system. Path length variations for different portions of the beam may cause blurring in parts of the image. Focusing at an image plane before or after the primary image plane also may result in distortion. Alternately, portions of the image beam may be directed to image at an incorrect position in the image plane.


In focused laser systems, OPD frequently appears as elongated or distorted spots. These defects appear in different axes in the near and far focus about the optimum focus or as "lobes" of energy projecting from the focused spot.

In vision systems, the image is not always diffraction limited, particularly with the larger apertures. As much as 1/2 or even 1 wave of distortion may produce acceptable results.

Mirror non-flatness in imaging systems is a common cause of OPD and is likely to appear as astigmatism in the image. Vertical and horizontal axes do not focus optimally at the same plane. This is seen in the two views of the image beam in the figure shown on the next page. The incorrect imaging position of certain bundles of light typically reduces contrast in the image.

The front view of the image beam, when reflected, forms a cylindrically deformed mirror. Because the beam's convergence is reduced, it focuses at a farther point than the undisturbed focus cone in the side view. The spot diagrams show that, in this case, the spot takes on an oval or enlarged size; however, it never attains the theoretical focus and size of the well-formed image on the right.

Astigmatism Caused by Cylindrical Mirror Surface



If the image quality does not meet expectations, test the lens system without the XY Scan Head. Frequently lens systems are to blame. Decentering, stress, and other manufacturing problems can cause image deformities similar to the mirrors.

7.2.2 Cosine (COS) Distortion


COS has two aspects: 1) Image Distortion and 2) Focus Distortion. These distortions are functions of the theoretical geometry of a two-axis, dynamically-corrected, post-objective, dynamically-focused scan system.

7.2.2.1 COS Image Distortion

Because the scanners point from a single point in a space on the target field, the incident angle varies with position. The following diagram depicts COS distortion for a vision system. The shape of the target images seen in the Scan Head pupil is shortened along the shadow axis to the dimension:

$$H' = H * \text{COS} (\text{theta})$$

COS Distortion in Vision



And, of course, in a laser scanning configuration, the imaged spot lengthens by the same percentage. The elongation axis is along a line drawn from the center field to the coordinate acquired. The equation to compute the incident angle is:

$$\theta_i = \text{ATAN} \left(\frac{\text{TAN}^2 \theta_x + \text{TAN}^2 \theta_y}{\text{COS}^2 \theta_y} \right)^{1/2}$$

The table following shows the distribution of cosine distortion over one quadrant of a typical scan field. Note that this distortion is only dependent on the X and Y scan angles. By computing the X and Y scanner angles for a field coordinate of a proposed field, you can look up the cosine distortion.

Distortion of Cosine Distortion in First Quadrant


% Cosine Distortion (as % of image size)

(deg) Y	0	2	4	6	8	10	12	14	16	18	20
20	6.8	6.8	7.0	7.3	7.7	8.2	8.8	9.5	10.4	11.3	12.4
18	5.4	5.5	5.6	5.9	6.3	6.8	7.5	8.2	9.1	10.0	11.1
16	4.2	4.3	4.4	4.7	5.1	5.7	6.3	7.0	7.9	8.8	10.0
14	3.2	3.2	3.4	3.7	4.1	4.6	5.3	6.0	6.9	7.9	9.0
12	2.3	2.4	2.5	2.8	3.2	3.8	4.4	5.2	6.1	7.1	8.2
10	1.6	1.6	1.8	2.1	2.5	3.1	3.7	4.5	5.4	6.4	7.5
8	1.0	1.1	1.2	1.5	2.0	2.5	3.2	4.0	4.9	5.9	7.0
6	0.6	0.6	0.8	1.1	1.5	2.1	2.7	3.5	4.4	5.4	6.6
4	0.2	0.3	0.5	0.8	1.2	1.8	2.4	3.2	4.1	5.2	6.3
2	0.1	0.1	0.3	0.6	1.0	1.6	2.3	3.0	4.0	5.0	6.1
0	0.0	0.1	0.2	0.6	1.0	1.5	2.2	3.0	3.9	4.9	6.1
(deg) X	0	2	4	6	8	10	12	14	16	18	20

7.2.2.2 COS Focus Distortion

When the image beam is incident on the target field at an angle as shown in the figure below, the path length to diagonal corners of the field varies as the angel theta calculated previously.

COS Focus Distortion



The next table shows the distribution of COS focus error in terms of the +/- focus depth required, expressed as a % of frame size (not to be confused with the field size).

GMAX M2/M2T 9.5mm XY Open Frame Head

<i>Distribution of COS Focus Error (as % of Image Size)</i>	(deg) Y											
	20	18	18	18	19	19	20	21	21	22	23	24
18	16	16	17	17	17	18	19	20	21	22	23	
16	14	14	15	15	16	17	17	18	19	21	22	
14	12	13	13	13	14	15	16	17	18	19	21	
12	11	11	11	12	13	14	15	16	17	18	20	
10	9	9	9	10	11	12	14	15	16	18	19	
8	7	7	8	9	10	11	12	14	15	17	18	
6	5	6	6	7	9	10	12	13	15	16	18	
4	4	4	5	6	8	9	11	13	14	16	17	
2	2	2	4	6	7	9	11	12	14	16	17	
0	0	2	3	5	7	9	10	12	14	15	17	
(deg) X	0	2	4	6	8	10	12	14	16	18	20	

For example, at the angle X=20°,Y=20° the variation in focus range is +/-24% of the frame size. A 0.25" square frame at corner field extreme has a field diagonal of 0.35" and thus requires 0.35 x 0.24 = +/- 0.08" depth of focus or blur would occur at the frame corners.

In most cases, large frame imaging prevents this problem by avoiding the extreme angles. Using small F numbers also alleviates the blur. Lasers, of course, have small image sizes and COS focus distortion is frequently ignored.

7.3 Drive Signals


Drive Signals (Step, Vector, Raster)The mechanical Scan Head design requirements vary depending on the criteria for optimal performance. Specifically, each of the three motions - STEP, VECTOR, or RASTER - has different performance definitions and requirements.

7.3.1 Step

Step motion occurs when the scanners rotate directly to a new position. This new position may be randomly located anywhere in the scanner's legal operating angle. The performance parameters of **Step** motion are:

- **Phase Delay**
The dwell after the input of a signal, before 1/% of the scanner motion occurs.
- **Motion**
The period during which 99% of the scanner motion is executed.
- **Settling**
After 99% of the motion is completed, the scanners settle and correct for any small position errors that might exist.
- **Error**
The +/- deviation from the programmed scan angle.

Step Motion



INPUT VOLTAGE COMMAND

POSITION OUTPUT VOLTAGE

Step operation requires the longest settling time due to the saturation effects of the amplifier and variations in scanner parameters. These allow for optimized tuning over small range of angles only. Use over the full range requires greater settling time. **Vector type slewing is the preferred way to obtain point-to-point motion. It is likely to be just as fast for large steps and faster for small ones.**

7.3.2 Vector

A **Vector** is created by the coordinated rotation of one or both axes of an XY Scan Head. Two types of vectors may be drawn:

- **Point-to-Point**
Vectors begin and end at drawn line endpoints. In most cases this is the fastest point-to-point transit.
- **Skywriting**
The scanners back up, then scan across the start point and across the end point, stopping beyond the end point. Although this type vector solves acceleration and deceleration exposure problems, it may not be faster than point-to-point. This is because the acceleration and deceleration lengths take significant time, and the ultimate drawing speed is limited by **Tracking Linearity**, the same as point-to-point.


There are two key aspects to accurate vectors:

1. The synchronization of the axes is a function of Scan Head design and servo tuning.
2. The control of the vector velocity on the target field.


The evaluation parameters of **Vector** scanning are:

- **Vector Rate**
The angular velocity of the "drawn" line or optical scan angle.
- **Phase Delay**
 - a) The time at the beginning of the vector after the ramp has begun, before the scanners have moved.
 - b) The period after the ramp has ended and the scanners continue at constant velocity toward the ending coordinate
- **Acceleration Length**
The length of line "drawn" while the scanners are accelerating to full velocity.

- Tracking Offset**
 The steady state error between input signal position and actual position during the vector motion.
- Tracking Linearity**
 The +/- deviations in tracking offset from the average offset of X and Y during the vector motion.
- Acceleration Error**
 At the start of each vector the two axes must accelerate identically to produce a straight line.
- Settling Error**
 After a vector is complete, the scanners must settle precisely to the starting point of the next vector. If not, the next vector will "squiggle" at the start. It looks like an acceleration error, but is caused by different servo factors.
- Settling Time**
 Time required for settling error to diminish to +/-70 μ radians typically.
- Vector Motion**



Example:
 Vector Performance ("G"
 Based XY Scan Heads)



7.3.3 Raster

A raster scan is generated by two scanners, one operating at high speed in a "sawtooth" pattern and one incrementing the line in the other axis. This is unidirectional scanning.

The alternate method of fast axis motion, "triangle" wave, is bi-directional raster. It is almost never used because of the inherent "Z" line spacing. The slow axis must step and settle extremely quickly in order to synchronize data in both directions at high speed with accuracy.

Unlike **Vector**, **Raster** writing is synchronized more with time than position. Raster scanning requires scan purity 10 or 20 times better than vector. The eye is very sensitive to raster errors. A single misplaced pixel can be quite apparent to the human observer. Not only must the scanner electronics be of high quality, but the scanner bearings must operate in a smooth "wobble free" way.


Raster error parameters are:

- **Write Period**
The time during the scan when the pixels are located.
- **Retrace**
The time between lines of pixels - retrace plus deceleration plus acceleration.
- **Wobble**
Deviation in pixel position perpendicular.
- **Jitter**
Deviation in pixel position along the fast scan axis.

Note:

For jitter and wobble values, refer to the component catalogs.

Raster Motion




7.4 XY Calculations

The calculations in this application note are computed for orthogonally-positioned, 2-mirror, 2-axis Scan Heads incorporating first surface on the center line of rotation mirrors.


When a 2-mirror, 2-axis Scan Head draws a box onto a flat field, the image is distorted in the familiar pincushion shape shown in the next figure.

Pincushion Distortion



The computation of scan coordinates for 2-mirror, 2-axis Scan Heads in a Cartesian axis frame work is easily introduced with Scan Heads with first surface mirrors. The following figure shows the geometry.

Cartesian Coordinate
Computation Geometry



The equations derived from the presented figure are as follows:

$$\varnothing_Y = \text{ATAN} \frac{Y}{Z}$$

$$\varnothing_X = \text{ATAN} \left(\frac{X}{(\sqrt{Z^2 + Y^2}) + e} \right)$$

$$fr = \sqrt{((\sqrt{Z^2 + Y^2}) + e)^2 + X^2}$$

Or, when arranged with respect to the variables of scanner angle:

$$Y = Z \text{TAN} \varnothing_Y$$

$$X = ((\sqrt{Z^2 + Y^2}) + e) \text{TAN} \varnothing$$

$$Z = \sqrt{(\sqrt{fr^2 - X^2} - e)^2 - Y^2}$$

The variables in each of these equations are:

X The distance on the target field from the center to the coordinate in question.

- Y** The distance on the target field from the center to the coordinate in question.
- Z** From the center of the distance perpendicular to the target to the pivotal axis of the Y mirror.
- \varnothing_x The optical scan angle of the X scanner (2 * the mech.).
- \varnothing_y The optical scan angle of the Y scanner (2 * the mech.).
- fr** The focus radius or the distance from a, the point of the mirror.
- e** The distance from points a to b. The shortest distance from the X mirror surface to the Y mirror surface at their respective rotation axes.


7.5 Linearity Distortions

Offset, first-surface mirrors are mass balanced about the center of rotation as shown in the next figure. Mass balance provides two attractive features:

1. It minimizes the bending moments that are generated whenever an eccentric mass is rotated.
2. It presents the minimum polar moment of inertia, therefore the least load on the scanner.

If the bending moment is forceful enough to deflect the scanner shaft, it may cause wobble or cross-axis scan deviations. Mass-balanced mirrors optimize performance when the velocity bending forces of the mirror become significant as compared to the bending stiffness of the scanner shaft.


Mass-balanced Offset Surfaces



Offset, first-surface mirrors, however, have two minor drawbacks. First, with rotation there is variation in the aperture exposed. Second, there are scan linearity errors associated with this construction. The next figure shows that the symmetry (a/b) of the main reflected ray shifts as the mirror surface rotates. At the extreme angles, the aperture symmetry (a/b) shifts from the center field case. Additional aperture compensates for this effect but increases inertia. For example, for offsets of 0.5 to 1.5 mm, inertia increases 5-10% and for larger offset of 3 mm, increases of 8-15% are realized.

Generally this is a small amount of inertial penalty, and in the case of large offset, the additional inertia is offset by sculpturing of the substrate as is done in integral mirrors.

Reflection at two angles



The offset T also causes an additional scan non linearity error. This error function is:

$$ERR = \frac{T - K \cdot \sin(\alpha)}{\cos(\alpha)}$$

Here T is the mirror surface offset; K is the input beam offset; and alpha is the mechanical scan angle.

Mass-balanced Scan Heads minimize these two problems by directing the input beam slightly below the pivotal center of the mirror. This helps to center the beam at the extreme shallow angle and minimizes the offset linearity error when scanning.

The presented graph is typical of single-axis, flat-field scan error for a mirror with a unity surface offset.



NOTE

The scan angle in the graph is optical for convenience (optical = 2 * mechanical).


To compute the error on the target field, first compute the X and Y scanner angles refer to Section “XY Calculations” on page 35. Next, look up each respective angle on this graph and multiply the scan error fraction times the mirror offset for each axis. Add the respective X and Y errors to the computed Cartesian field coordinates directly. The focus path length error is the sum of the X and Y errors.

*Example:
Scan Error*

SCAN HEAD	T OFFSET	X ERR	Y ERR	Z ERR
XY0507 (G120DT)	0.5 mm	0.014 mm	0.011 mm	0.025 mm
XY3037 (G325DT)	2.0 mm	0.054 mm	0.042 mm	0.960 mm

Maximum peak-to-peak errors

Scan Error vs. Scan Angle



It is usually not necessary to evaluate errors for each configuration. The following analysis shows that mass balance scanning non linearities are generally less than inherent scanner non linearities. You may evaluate the consequence of this error by comparing it to nominal scanner non linearity, which is specified at +/-0.3% of full field. Peak-to-peak error on the target field, therefore, may be computed by:

Scanner Field error	=	$D * 2SLE * SA$
D	=	scan radius
SLE	=	scanner linearity error, peak-to-peak
SA	=	scanner angle, peak-to-peak

When equated to the mirror offset error:

$$MBM_{err} \bullet AR = D(2 \bullet SLE) \bullet SA$$

MBM_{err} = scan error caused by mirror offset

$$AR = \text{acceptability ratio} = \frac{\text{scanner linearity error}}{\text{scan mirror error}}$$

The most useful form of this equation comes from solving for D:

$$D = \frac{AR}{0.006 \bullet 0.7_{(\text{radian, peak-to-peak})}}$$

Thus $D = AR \bullet 238^\circ (MBM_{err})$, where SLE is assumed to be 0.3% peak

So, for the two Scan Heads mentioned, we have solved for D at three acceptability ratios.

	AR = 1	AR = 10	AR = 50
XY0507... D =	3.3 mm	33.0 mm	156.0 mm
XY3035... D =	12.6 mm	126.0 mm	630.0 mm
Increase in Error	100%	10%	2%

When short scan radii must be used, off-center mirrors probably will not suffice. If linearity is a concern, use scan radii greater than those shown in the AR=10 column.

As mentioned before, the focus path change is the sum of X and Y errors. Actually this "error" improves flat field focus; however, the improvement is not large enough to be significant, and additional flat field focus correction is required.


8. APPENDIX B

8.1 Outline Drawings / Data Sheets

• Driver Board Block Diagram(s) Block Diagram	DWG #: 3BD-16835
• Driver Board Connectors / SIC Backplane Schematic Backplane, Schematic	DWG #: 3BD-16836
• Board Connectors	DWG #: 3WD-16841
• M2 Scanner Data Sheet M2 Scanner Data Sheet	
• Outline, M2 9.5mm XY Head Outline Drawing with M2	DWG #: 3CD-16384
• Outline, M2T 9.5mm XY Head Outline Drawing with M2T	DWG #: 3CD-18018
• Outline, M2T 9.5mm XY w/ Baseplate	DWG #: 3CD-18016

SYM	REVISION	RECORD	DATE	APPVD.
A	RELEASED TO PRE-PRODUCTION	ECN-10093		
B	REV PER	ECD-8493		


PROPERTY OF GSI LUMONICS
 This document is and shall remain an unpublished work of GSI Lumonics protected by copyright. It is loaned for limited purposes only. It remains the property of GSI Lumonics. It will be reproduced, used, or disclosed to anyone not having a need-to-know consistent with the purpose of the loan, without written consent of GSI Lumonics.




MATERIAL		TREATMENT	
UNLESS SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: XX = ± .01 .XXX = ± .005 .XXXX = ± .0010 ANG. = ± 0°30'	FUNCTION	NAME	DATE
REMOVE ALL BURRS AND SHARP EDGES.	DRAWN	B.P. STONE	4/17/95
SCALE NONE	CHECKER		
in [mm]	D.A.	R. AQUILAND	8/25/95
	DES. ENG.	A. LOWEN	8/23/95
	MFG. ENG.	G. PAOLUCCI	8/23/95
	PROJ. MGR.		
CAD FILE No. GMAX\16835-0B	CAGE No.	TITLE	
XY HEAD DRIVER BLOCK DIAGRAM		SIZE	DRAWING NUMBER
B	3BD-16835	REV	B
gsi Lumonics WILMINGTON, MA			

PROPERTY OF GSI LUMONICS
 This document is and shall remain an unpublished work of GSI Lumonics protected by copyright; is loaned for letter purposes only; remains the property of GSI Lumonics; and will be reproduced, used, or disclosed to anyone not having a need-to-know consistent with the purpose of the loan, without written consent of GSI Lumonics.

SYM	REVISION	RECORD	DATE	APPVD.
A	RELEASED TO PRE-PRODUCTION ECN-10093			
B	REV PER ECO-8493			



MATERIAL			TREATMENT			
UNLESS SPECIFIED:	FUNCTION	NAME	DATE	CAD FILE No.	GMAX16836-0B	CAGE No.
DIMENSIONS ARE IN INCHES	DRAWN	B.P. STONE	4/17/95			
TOLERANCES: .XX = ± .01	CHECKER	R. AQUILANO	8/25/95	TITLE		
.XXX = ± .005	Q.A.	A. LOWEN	8/23/95	XY HEAD DRIVER		
.XXXX = ± .0010	DES. ENG.	G. PADLUCCI	8/23/95	BLOCK DIAGRAM		
ANG. = ± 0°30'	MFG. ENG.			SIZE	DRAWING NUMBER	REV
REMOVE ALL BURRS AND SHARP EDGES	PROJ. MGR.			B	3BD-16836	B
SCALE NONE				gsi Lumonics WILMINGTON, MA		



MATERIAL	TREATMENT	DATE	NAME	FUNCTION	FILE No.	REV
UNLESS SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES .XX = ± .01 .XXX = ± .010 .XXXX = ± .010 .XXXXX = ± .010		4/18/95	REP STONE	DRAMAN	06AX16841-03	B
HEADIVE ALL BURS AND SHARP EDGES TO BE NONE		8/25/95	R. ABULAND	CHECKER		
		8/24/95	A. LIVEN	DES. ENGR.		
			G. PAULCCI	DES. ENGR.		
				PROJ. MGR.		

REV	DATE	DESCRIPTION
B	4/18/95	RELEASED TO PRE-PRODUCTION
A	8/25/95	REVISION

BOARD CONNECTORS

C&I LUMONICS
 LUMONICS, INC.

DRAWING NUMBER: **EVD-16841**

M2 Series Optical Scanners

Features

- ▶ Repeatability to 5 μ radians optical
- ▶ Non-linearity as low as 0.05%
- ▶ Low sensor thermal drift
- ▶ Low wobble and jitter
- ▶ Rugged moving-magnet rotor design
- ▶ Higher precision writing speeds
- ▶ Angles up to ± 30 degrees optical
- ▶ Lightweight 210 g

The new M2 optical scanners offer an innovative motor design coupled with an advanced capacitive position detector. This new design offers higher speeds, wider angles, lower linearity error and improved operational stability over existing scanner technology.

Using moving-magnet technology, this scanner incorporates the more familiar characteristics of both moving-coil and moving-iron torque


transducers. The M2 has the low inertia rigidity and low temperature control of moving-iron devices as well as the low inductance of moving-coil units. This new scanner, however, is smaller and lighter than either moving-coil or moving-iron models.

Our rugged M2 is available in two configurations. The M2T is our high performance unit, the M2 the standard. Both the M2T and M2, when used with GSI's innovative servo-loop, achieve higher bandwidth, faster mirror settling, and lower drift than other designs.

The M2T is designed to provide a higher degree of gain and offset stability in environments where moderate ambient temperature changes are anticipated.

High-speed laser beam positioning now meets the absolute accuracy requirements for stereolithography, micromachining, imaging, and communications.

Customization is available for OEM's.




M2 Series Optical Scanners

Specifications¹


Parameters	Units	M2	M2T
Rated Excursions, max.	degrees optical	± 30	±30
Rotor Inertia	g-cm ²	1.7	1.7
Wobble ^{2,4}	μrad	1.5	1.5
Jitter ^{2,4}	μrad	6	6
Repeatability ²	μrad	12	12
Magnetic Driver			
Coil Resistance	Ohms	4.5	4.5
Coil Inductance	mH, 1 kHz	0.62	0.62
Torque Constant	Nm/A	.023	.023
Peak Current/Instantaneous	A	25	25
Thermal Conductivity (Coil to Case)	°C/W	2.5	2.5
Position Sensor¹			
Angular Sensitivity	μA/° optical	11	11
Non-Linearity	% max.	0.05	0.05
Typical Zero Drift ²	μ radian/° C	18	1.5
Typical Gain Drift ³	ppm/° C	-60	-10

Notes: 1. Angular specifications in terms of optical deflection.
2. STD deviation.

3. Distribution STD deviation is 27 ppm/°C and 3 ppm/°C for M2 and M2T respectively.
4. Depends strongly on mirror size and operational speed.




M2 Outline Drawing





M2T Outline Drawing

PROPERTY OF GSI LUMONICS
 This document is the property of GSI LUMONICS. It is loaned to you for your information only. It is not to be reproduced, stored in a retrieval system, or transmitted in any form or by any means, electronic, mechanical, photocopying, recording, or by any information storage and retrieval system, without the prior written permission of GSI LUMONICS.



127 ±.002 WIDE SLOT X .15 DP
 [3.200 ±.05 WIDE SLOT X 3.81 DP]
 FULL RADIUS ON ENDS.

3X Ø.209 THRU
 [3X Ø5.31 THRU]



SYM	REVISION	RECORD	DATE	APP'D.
2	REV PER ECN-9919		6/2/95	ALL
3	REV PER ECN-10048		7/17/95	GP.
A	RELEASED TO PRODUCTION ECN-10093		8/23/95	ALL
B	LAST REV WAS 3		10/11/96	GP.
C	REV PER ECN-10754		5/14/99	D.B.
D	REV PER ECD-8583			

MATERIAL		TREATMENT	
FUNCTION	NAME	DATE	CAD FILE No. GMAX\16384-0D
DRAWN	KEN WYNN	2/21/95	CAGE No.
CHECKER			TITLE
D.A.	R. ADUILAND	8/25/95	OUTLINE, M2 9.5mm XY HEAD
DES. ENG.	A. LOWEN	6/2/95	
MFG. ENG.	G. PADLUCCI	8/24/95	
PROD. MGR.	A. LOWEN	2/25/95	

UNLESS SPECIFIED, DIMENSIONS ARE IN INCHES
 TOLERANCES: .XX = ±.01
 .XXX = ±.005
 .XXXX = ±.0010
 ANG. = ± 0°30'




REMOVE ALL BURRS AND SHARP EDGES
 SCALE 1=1
 IN [mm]

gsl Lumonics
 WILMINGTON, MA

SIZE C 3CD-16384
 DRAWING NUMBER
 REV D

©2002/03/04 BY CSI LUMONICS
 This document is not valid, except as an unaltered part of CSI Lumonics products. Any
 copy or use of this document for other purposes, in whole or in part, without the written
 consent of CSI Lumonics is prohibited. The information contained herein is confidential and
 its disclosure to third parties without the written consent of CSI Lumonics is prohibited.

SYM	REVISION	RECORD	DATE	APPRVD.
A	RELEASED TO PRODUCTION	ECN-10729		
B	REV. PER ECD-8493		5/14/99	D.B.
C	REV. PER ECD-8583			



.127 ±.002 WIDE SLOT X .15 DP
 [3.23 ±.05 WIDE SLOT X 3.81 DP]
 FULL RADIUS ON ENDS.




3X Ø.209 THRU
 [3X Ø5.31 THRU]

MATERIAL		TREATMENT	
NAME	DATE	CAD FILE No.	GMAX18018-0C
B.P. STONE	9/18/96		
FUNCTION	DATE	TITLE	
DRAWN	9/18/96	OUTLINE, M2T 9.5mm XY HEAD	
CHECKER			
.XXX = ± .01			
.XXX = ± .005			
.XXX = ± .0010			
ANG. = ± 0.30			
DES. ENG.	10/4/96		
MFG. ENG.	10/4/96		
PROJ. MGR.			
SCALE	1=1		
in			
[mm]			
UNLESS SPECIFIED: DIMENSIONS ARE IN INCHES TOLERANCES: .XX = ± .01 .XXX = ± .005 .XXX = ± .0010 ANG. = ± 0.30		CAGE No.	
REMOVE ALL BURRS AND SHARP EDGES		C	
DRAWING NUMBER		3CD-18018	
REV		C	

csi Lumonics
 WILMINGTON, MA

PROPERTY OF GSI LUMINICS
 This drawing is the property of GSI LUMINICS. It is to be used for manufacturing purposes only. It is not to be reproduced, copied, or distributed without the written consent of GSI LUMINICS. All dimensions are in inches unless otherwise specified. All tolerances are as shown. All dimensions are to be held unless otherwise specified. All dimensions are to be held unless otherwise specified. All dimensions are to be held unless otherwise specified.

SYM	REVISION	RECORD	DATE	APPVD.
1	RELEASED TO PRE-PROD	ECN-10729		
2	REV PER	ECN-51321	3/20/96	G.P.
A	REV PER	ECN-8493	5/14/99	D.B.
B	REV PER	ECN-8583		



MATERIAL		TREATMENT	
UNLESS SPECIFIED:	FUNCTION	NAME	DATE
DIMENSIONS ARE IN INCHES	DRAWN	B.P. STONE	9/18/96
TOLERANCES: .XX = ± .01	CHECKER		
.XXX = ± .005			
.XXXX = ± .0010			
ANG. = ± 0°30'			
REMOVE ALL BURRS AND SHARP EDGES	DES. ENG.	A. LDVEN	10/4/96
SCALE	MFG. ENG.	G. PAOLUCCI	10/4/96
1/8" [mm]	PRJ. MGR.		
S=1			
CAD FILE No. GMAX18016-0B		CAGE No.	
TITLE			
OUTLINE, M2T 9.5mm XY W/BASEPLATE			
REV	DRAWING NUMBER	SIZE	REV
	3CD-18016	C	B

gsi Luminics
 WILMINGTON, MA

INDEX

	—C—	Scratch/Dig, 24	
Customer Support, 3		Selection, 21	
		Specifications, 6	
		Types, 22	
	—D—		—P—
Driver Card		Package list, 5	
Address Selection, 13		Power Requirements, 12	
Backplane, Schematic, 41			
Block Diagram, 41			—S—
Diagnostic Connector, 13		Scan Head	
Features, 12		Accuracy, 23	
Front Panel Indicators, 12		Aperture, 21	
Scanner Cable, 12		Drive Signals (Step, Vector, Raster), 31	
SIC Backplane Card, 12		Heat Sink, 16	
Temperature Controller, 14		Installation, 11	
	—F—	M2 Scanner Data Sheet, 41	
Federal Register, 8		Max. Temperature, 14	
		Mirror Aperture, 14	
	—L—	Operating Environment, 17	
Laser		Operating Instructions, 11	
Classes, 8		Outline Drawing with M2, 41	
Hazard Zones, 9		Outline Drawing with M2T, 41	
Shutter Installation, 9		Outline Drawing with M2T, Baseplate, 41	
Shutter Location, 9		Scan Angle, 14	
Warning Label, 8		Scanner, 14	
		Types, 5	
	—M—	System Performance Data, 16	
Maintenance			—U—
Mirror Cleaning, 19		Unpacking, 3	
Scan Head, 19			
Mirror			—W—
Cleaning, 19		Warranty, 2	
Flatness, 24			
Reflectivity, 25			